



## RS2100 Series Technical Accessory Guide



NOTE: This document is only for general reference. Solutions Pathway and related PMBs should be used for product availability, pricing, and final solution selection.





\* Zebra does not endorse or specifically recommend any **third-party products, accessories, or hardware**. ZEBRA DISCLAIMS ANY AND ALL LIABILITY, INCLUDING ANY EXPRESS OR IMPLIED WARRANTIES, WHETHER ORAL OR WRITTEN, FOR SUCH THIRD PARTY PRODUCTS, ACCESSORIES, OR HARDWARE. THE CUSTOMER ACKNOWLEDGES THAT NO REPRESENTATION HAS BEEN MADE BY ZEBRA AS TO THE FITNESS OF THE THIRD-PARTY PRODUCTS, ACCESSORIES, OR HARDWARE FOR THE CUSTOMER'S INTENDED PURPOSE.


### Cradles/Charging

Part Number	Picture	Description	Notes	Required Items
CRD-RS2X-2SCHG-01		2-Slot Charging Cradle	<ul style="list-style-type: none"> <li>▶ Will charge up to 2 RS2100 units</li> <li>▶ Hand mount must be removed from RS2100 to dock in cradle. Cradle connects to contacts on the bottom of scanner.</li> <li>▶ Status lights on the RS2100 unit indicate its charging status.</li> <li>▶ Cradle can be easily mounted vertically or horizontally on tabletops, walls, poles, etc. using zip ties or screws (not included).</li> <li>▶ Charge times (at room temperature when using PWR-WUA5V12Wxx Power Adapter): 0- 90% in less than 2.5 hours</li> </ul>	<ul style="list-style-type: none"> <li>▶ USB Power Adapter (PWR-WUA5V12W0US - or country specific version)</li> <li>▶ USB-C Cable (CBL-TC5X-USBC2A-01)</li> </ul>
CRD-RS2X-20SCHG-01		20-Slot Charging ShareCradle	<ul style="list-style-type: none"> <li>▶ Will charge up to 20 RS2100 units.</li> <li>▶ Can be racked/ mounted in a standard 19 inch rack system via the mounting accessory (BRKT-SCRD-SMRK-01).</li> </ul>	<ul style="list-style-type: none"> <li>▶ Power Supply (PWR-BGA12V108W0WW)</li> <li>▶ DC Line Cord (CBL-DC-381A1-01)</li> <li>▶ AC Line Cord (23844-00-00F or country specific version)</li> </ul>
BRKT-SCRD-SMRK-01		Multi-Slot Wall/Rack Mount Bracket	<ul style="list-style-type: none"> <li>▶ Allows for rack and wall mounting of one 20-Slot Charging Cradle.</li> <li>▶ Bracket can be mounted on standard 19" network rack or on a wall.</li> <li>▶ Cable routing slots &amp; removable power supply holder tray.</li> <li>▶ Adjustable tabs &amp; screw mounts for easy hanging/installation.</li> <li>▶ Adjustable orientations - horizontal, vertical, angled.</li> <li>▶ See the Bluetooth-Generic Accessories TAG for info on 3rd party Network Racks that can be used for mounting this bracket.</li> </ul>	



### Bluetooth Communications Adapters

Part Number	Picture	Description	Notes	Required Items
-------------	---------	-------------	-------	----------------


BT-RS5X6-DNGL-01		Bluetooth Adapter	<ul style="list-style-type: none"> <li>▶ Allows RS2100 to be easily connected with hosts that do not have a Bluetooth radio for direct communication.</li> <li>▶ Pairing barcode on adapter is scanned to instantly pair with the RS2100.</li> <li>▶ Up to 7 scanners can be paired per adapter.</li> <li>▶ Paging button on adapter will trigger all paired scanners to beep, ideal for locating misplaced/hidden scanners.</li> <li>▶ Adapter is powered from host via USB.</li> <li>▶ Adapter can be easily mounted vertically or horizontally on tabletops, walls, poles, etc. using zip ties or screws (not included).</li> </ul>	▶ USB Scanner Cable (CBA-U46-S07ZAR)
KT-RS5X6-BTDCBL-01		Bluetooth Adapter KIT	<ul style="list-style-type: none"> <li>▶ Allows RS2100 to be easily connected with hosts that do not have a Bluetooth radio for direct communication.</li> <li>▶ Pairing barcode on adapter is scanned to instantly pair with the RS2100.</li> <li>▶ Up to 7 scanners can be paired per adapter.</li> <li>▶ Paging button on adapter will trigger all paired scanners to beep, ideal for locating misplaced/hidden scanners.</li> <li>▶ Adapter is powered from host via USB.</li> <li>▶ Adapter can be easily mounted vertically or horizontally on tabletops, walls, poles, etc. using zip ties or screws (not included).</li> <li>▶ Kit includes: <ul style="list-style-type: none"> <li>- Bluetooth Adapter (BT-RS5X6-DNGL-01)</li> <li>- USB Scanner Cable (CBA-U46-S07ZAR)</li> </ul> </li> </ul>	
CBA-U46-S07ZAR		Shielded USB Cable: Series A Connector, 7ft. Straight	▶ Used with Bluetooth Adapter (BT-RS5X6-DNGL-01)	
STB3678-C100F3WW STB3678-C138E8NA (TAA compliant) STB3678-C100F3CN (for use in mainland China only)		Communication Cradle	<ul style="list-style-type: none"> <li>▶ Allows RS2100 to be easily connected with hosts that do not have a Bluetooth radio for direct communication.</li> <li>▶ Pairing barcode on Cradle is scanned to instantly pair with the RS2100.</li> <li>▶ Up to 7 scanners can be paired per cradle.</li> </ul>	▶ Host communication cable and possibly a power supply depending on the host cable type.  See 36XX Series Scanner accessory document for cable and power supply options


<p>FLB3678-C100F3WW</p> <p>FLB3678-C100F3CN (for use in mainland China only)</p> <p>► To be discontinued 7/2025 - see DN/PMB-11592.</p>		<p><b>Sealed Communication Cradle</b></p>	<p>► Allows RS2100 to be easily connected with hosts that do not have a Bluetooth radio for direct communication.</p> <p>► Pairing barcode on Cradle is scanned to instantly pair with the RS2100.</p> <p>► IP65 sealed for installations requiring wash-down (i.e. forklift installations).</p> <p>► Up to 7 scanners can be paired per cradle.</p>	<p>► Host communication cable and possibly a power supply depending on the host cable type.</p> <p>See 36XX Series Scanner accessory document for cable and power supply options</p>
---	---	---	--	--

**Soft Goods**

Part Number	Picture	Description	Notes	Required Items
<p>SG-RS2X-HMTRA-01 (single)</p> <p>SG-RS2X-HMTRA-10 (10 pack)</p>		<p>Hand Mount With Embedded Trigger, <b>Right Hand</b></p>	<p>► Required to be used with each RS2100 unit. A Hand Mount is not included with the scanner.</p> <p>► One size fits all</p> <p>► Trigger button life cycle is about 500K scans</p>	
<p>SG-RS2X-HMTLA-01 (single)</p> <p>SG-RS2X-HMTLA-10 (10 pack)</p>		<p>Hand Mount With Embedded Trigger, <b>Left Hand</b></p>	<p>► Required to be used with each RS2100 unit. A Hand Mount is not included with the scanner.</p> <p>► One size fits all</p> <p>► Trigger button life cycle is about 500K scans</p>	

**Power Cords/Power Supplies**

Part Number	Picture	Description	Notes	Required Items
<p>PWR-WUA5V12W0US (US plug style)</p> <p>PWR-WUA5V12W0GB (UK plug style)</p> <p>PWR-WUA5V12W0EU (EU plug style)</p> <p>PWR-WUA5V12W0AU (Australia plug style)</p> <p>PWR-WUA5V12W0CN (China plug style)</p> <p>PWR-WUA5V12W0IN (India plug style)</p> <p>PWR-WUA5V12W0KR (Korea plug style)</p> <p>PWR-WUA5V12W0BR (Brazil plug style)</p> <p>PWR-WUA5V12W0LA (Argentina/Chile/Mexico plug styles)</p>		<p>USB Power Supply</p>	<p>► Used with USB-C Cable to power 2-Slot Cradle (CRD-RS2X-2SCHG-01)</p> <p>► Provides higher current (2.5A) for faster charging</p> <p>► 100-240 VAC, 5 V, 2.5 A</p>	

CBL-TC5X-USBC2A-01		USB-C cable	<ul style="list-style-type: none"> <li>▶ Used to power 2-Slot Cradle (CRD-RS2X-2SCHG-01).</li> <li>▶ USB-A to USB-C cable</li> <li>▶ Cable length is 1M (~3.25 ft.)</li> </ul>	
CBL-DC-381A1-01		DC Power Cord	<ul style="list-style-type: none"> <li>▶ Used to power 20-Slot ShareCradle when using Level VI Efficiency power supply (PWR-BGA12V108W0WW)</li> </ul>	
CBL-DC-382A1-01		DC Power Cord	<ul style="list-style-type: none"> <li>▶ Used with Power Supply PWR-BGA12V108W0WW to power 20-Slot ShareCradle.</li> <li>▶ This cable includes a black extension release latch/clip that is needed when powering legacy non-ShareCradle design multi-slot cradles. This cable can be used instead of CBL-DC-381A1-01, if needed.</li> <li>▶ CBL-DC-381A1-01 is the preferred cable to use.</li> </ul>	
PWR-BGA12V108W0WW		Power Supply	<ul style="list-style-type: none"> <li>▶ Used to power 20-Slot ShareCradle.</li> <li>▶ 100-240 VAC, 12V, 9A, 108W</li> <li>▶ Provides US DOE Level VI compliance for power efficiency.</li> </ul>	<ul style="list-style-type: none"> <li>▶ DC Line Cord (CBL-DC-381A1-01)</li> <li>▶ AC Line Cord (23844-00-00F or country specific version)</li> </ul>
23844-00-00R		AC Line Cord	<ul style="list-style-type: none"> <li>▶ This AC Line Cord is for use in North America. See the <b>AC Line Cords by Country</b> TAG for comparable line cords to use in other countries.</li> </ul>	